


Dive Plane Kit – C8 Z06 Corvette

Install Manual



Author: M. Deckard Release Date: 2025/10/06 Approvals: E. Hazen

Document Revisions

| Rev | Date | Author | Description |
|-----|------------|------------|-----------------------------------|
| 01 | 2025/10/06 | M. Deckard | Initial release of install manual |
| | | | |
| | | | |
| | | | |



ENGINEERING | NORTH AMERICA REVISION: **R01**

Author: M. Deckard Date: 2025/10/06 Recipients: Public

Dive Plane Kit, C8 Z06 Corvette-Install Manual

Contents

| Introduction | 3 |
|---------------------------|---|
| Overview | 3 |
| Difficulty | 3 |
| Time Required | |
| Tools Recommended | 3 |
| Dive Plane Kit Components | 4 |
| Dive Plane Kit Install. | 5 |



Dive Plane Kit, C8 Z06 Corvette-Install Manual

Introduction

Overview: Detailed instructions on installing the Verus Engineering Dive Plane Kit for the C8 Z06 Corvette.

Difficulty: Moderate

Time Required: 0.5 - 1hour

Tools Recommended:

- 50/50 Mix of Isopropyl Alcohol and Water
- Microfiber Towel
- Painters tape
- Scissors or razor blade





Dive Plane Kit, C8 Z06 Corvette-Install Manual

Dive Plane Kit Components

- (1) Left Upper Dive Plane
- (1) Right Upper Dive Plane
- (1) Left Lower Dive Plane
- (1) Right Lower Dive Plane
- (1) Left Upper Die-Cut 3M VHB Tape
- (1) Right Upper Die-Cut 3M VHB Tape
- (1) Left Lower Die-Cut 3M VHB Tape
- (1) Right Lower Die-Cut 3M VHB Tape
- (1) Template





Dive Plane Kit, C8 Z06 Corvette-Install Manual

Dive Plane Kit Install

- 1. Verus Engineering is not responsible for damage to you or your vehicle by following this manual and/or installing Verus Engineering products. Please seek professional service/guidance if you are uncomfortable/incapable of installing this in a safe manner. Contact us at support@verus-engineering.com if you have any questions/concerns.
- 2. For best adhesion, the following guidelines should be met per 3M for install: Minimal temperature for install should be 50 degrees Fahrenheit. At room temperature approximately 50% of ultimate bond strength will be achieved after 20 minutes, 90% after 24 hours and 100% after 72 hours.
- **3.** The first task will be to use scissors or a razor blade to cut out the templates.




4. Next, we will need to prepare a dive plane. Using our clean microfiber and 50/50 mixture, clean the mounting flange of the dive plane (outlined in yellow below).





Dive Plane Kit, C8 Z06 Corvette-Install Manual

5. Now that the dive plane mounting surface is clean and dry, locate the dive plane's corresponding 3M VHB tape. Note: The 3M VHB tape sections are very similar in shape. Use the curves on either end of the tape to match them up correctly.



6. Pull back the white backing of the 3M VHB and place it on the dive plane. Note: For proper adhesion, massage the 3M VHB tape into place to ensure no air bubbles are trapped under it.






- 7. Repeat Step 3 5 for the remaining (3) dive planes.
- **8.** Once all of the dive planes have 3M VHB tape installed, set them aside and move to the front bumper of your car.
- 9. Using a clean microfiber and your 50/50 mixture again, clean the area of the bumper (outlined in yellow below) that the dive planes and template will mount on. Note: This step is especially important to those who have cars with a ceramic coating applied. The ceramic coating will need removed in this area for the 3M VHB to adhere properly.



Dive Plane Kit, C8 Z06 Corvette-Install Manual




10. Follow the labelled instructions for placement on the template and use your painter's tape to install it on the car.





Dive Plane Kit, C8 Z06 Corvette-Install Manual

11. Placing one dive plane at a time, line up each dive plane with the template and peel off the red backing as you go. Massage the 3M VHB into place to promote proper adhesion. Note: The larger dive plane that wraps around the front of the bumper installs in the lower location.



12. When you have placed both dive planes on one side, remove your template.



13. Repeat Step 8 – 11 for the remaining side.



Dive Plane Kit, C8 Z06 Corvette-Install Manual

- **14.** Congratulations on installing the Dive Plane Kit for the C8 Z06 Corvette! For more information on performance, please visit our website and take a look at our informative packet.
- **15.** Please send any questions, comments, concerns, or photos to Verus Engineering via e-mail; support@verus-engineering.com.



